




Lenovo ThinkPad Yoga 14 20FY Back Cover Replacement

This guide will show you how to remove the back cover on the Lenovo ThinkPad Yoga 14 20FY.


Written By: Patrick Kramer



INTRODUCTION

This guide explains how to safely remove the back panel of the Lenovo ThinkPad Yoga 20FY. It provides the tools needed as well as the quickest and easiest way to complete the task.

Step 1 — Back Cover



- Remove the indicated 9 M2 x 6 mm nylon-coated screws using a Phillips head screwdriver.

i The screws do not come all the way out. Do not force them out.

Step 2



- After removing all of the screws, gently lift up on all covers to remove the back plate and reveal the interior of the device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 06:59:19 AM.